

**CAUTION:** The device may only be connected and installed by a qualified electrician. All applicable regulations, legislation and building codes must be observed. Incorrect installation of the device can cause irreparable damage to the device and the connected LEDs.

### 12V - 28V DC IN

Connect the LED driver to a 12-28V DC short-circuit proof power supply unit (PSU). To do so, connect the PSU's positive voltage supply wire to the VDC+ connector and the PSU's negative voltage supply wire to the VDC- connector.

### EXT in

You have the possibility to connect a 47kΩ potentiometer to the LED driver's Ext in+ and Ext in- connector for local dimming.

### DA+ / DA-

Use these connectors to connect the LED driver to a DALI network. Always combine a DA+ and a DA- connector for either data input or data output.

### TOOLbox pro

You can connect a TOOLbox pro to a DA+ and DA- connector. Using the freely downloadable FluxTool software, you can then use the DALI sliders as a simple test setup. Note that the FluxTool software is not a DALI commissioning tool.

### LED groups


Indicates the location of the connectors for your LED strips. LINEARdrive 210D is a single-channel driver, meaning both LED groups are seen as one DALI ballast.

LINEARdrive 220D is a dual-channel LED driver: the two LED groups can be controlled as two separate DALI ballasts.

**Connecting two LED strips**

Maximum current for both LED outputs together is 8A.

You are free to divide the 8A over the two LED outputs in any way you want.

**Connecting one LED strip**

Maximum current for both LED outputs together is 8A.

When connecting only one LED strip, the maximum current for the output it is connected to is also 8A.

